


AUDIO OUTPUT INSTRUCTION

MXL & MXR CONSOLE

OUTPUT BOARD TERMINALS (PARTIAL VIEW)



MONITOR OUTPUT

"ANY MIC MODULE
PLACED "ON AIR"
MUTES MONITOR
OUTPUT.

ANY MODULE PUT
IN "CUE" DIMS
MONITOR LEVEL
-10db. DIM MAY BE
ADJUSTED FROM
-10db TO FULL MUTE

BUSS OUTPUT

PGM AUD MON1 MON2
+4dbu OUT WITH 0dbu IN
200 ohm OUTPUT
IMPEDEANCE
MAX. OUTPUT +28dbu